








Step 1: Accessories

| | | | |
|---|---------------|----|---|
| A | M6*15 | 6 |  |
| B | M6*20 | 7 |  |
| C | M6*25 | 15 |  |
| D | Hexagonal Key | 1 |  |
| E | Iron Piece | 1 |  |




Step 4:



Use 8 M6*25 screws to tighten the seat.


Step 2:



Use 6 M6*15 screws to fix the iron sheet to the wooden frame.


Note: Because there are slight gaps between the wooden frames, when screwing in the screws, you should first align all the screws with the holes of the wooden frame and the iron sheet, and then tighten them one by one.

Step 5:



Align the four holes on the back of the back pad with the back panel and hang it on.

Step 3:




1. Use 3 M6*20 screws and 3 M6*25 screws to lock the backrest and rear feet.

2. Use 4 M6*20 screws to gently lock them into the four holes on the side of the back panel.

Note: The 4 M6*20 screws on the backrest do not need to be fully tightened, otherwise they will easily screw through the wood board. Just tighten the screws 3-4 times, and leave half of the screws exposed to hang the back cushion.

Step 6:



Use 4 M6*25 screws to lock the seat cushion and seat plate.

Note: Do not tighten the screws directly. All screws should be positioned before they can be fully tightened.