

CC023-Drawer Installation Instruction

Please be sure to use a manual screwdriver and refrain from using an electric drill.



1. Product accessories and quantity

			
Eccentric wheel + eccentric rod	3.5*12 self-tapping screws	Curved aluminum handle	4*14 handle screw
D14x14 (spare plus 2)	A1 x 26 (spare plus 2)	J1X3	B14x7 (spare plus 1)
			
4*35 self-tapping screws	small nails	iron shelf pin	Tall hinge
B3 x 34 (spare plus 2)	K20 x 21 (spare plus 2)	KOX19 (spare plus 2)	F2*4
			
screwdriver			
1			

Kind tips:

1. When installing, please refer to the drawings to distinguish the boards.

The color of the product is not subject to the instructions;

2. Tighten the screws 70%, and then tighten them after everything is completed!

3. Some boards have a red side, and the red side faces down or inward.

4. Please read all the drawings before proceeding with installation.

2. Installation steps of eccentric parts



Screw the eccentric rod to the board



Find the corresponding board and insert it



find round hole



Insert the eccentric wheel into the round hole




Rotate 180° clockwise to lock
the board left and right



3. Start the installation: drawer partial installation

<1>



No. 8 board has no holes on the front and is screwed into D14 (eccentric rod)



D14 (eccentric rod)

D14 (eccentric rod)

④ Drawer panel




⑤ Drawer left side panel



⑩ Drawer right side panel



<2>



1. Insert drawer bottom plate No. 18

2. Rotate D14 (eccentric wheel) clockwise

lock the board


(18)



⑧ Drawer bottom




⑦ Drawer back panel



Install the remaining drawers in the same way




The drawer part is installed



4. The upper part of the cabinet is installed as follows

<1>



2. The side with more holes on No. 3 board is at the bottom and installed oppositely.



② Upper left panel



③ Upper right panel



① Cover





4*35 self-tapping screws

B3*4



5. The lower part of the cabinet is installed as follows

<1>


Note: D14 (eccentric rod) on No. 8 board Install towards the rear



⑧ Connect the laminate ④ Lower left side panel ⑤ Lower right panel



Eccentric rod
D14*4

4*35 self-tapping screws
B3*4

<2>




① Lower fixed shelf


4*35 self-tapping screws
B3*4



⑦ Base plate



⑪ skirting board



6. The overall installation is as follows:


<1>

Turn the whole thing


over and connect the upper and lower parts



Knock in K20 with a tool hammer (you need to bring your own tool hammer)



Dear, for the sake of beauty, it is recommended to tape the gap on the back panel until it is flush (you need to bring your own tape)



② Large back panel



③ Small back panel


small nails
K20*19

Straighten the whole



2. Insert KO on board No. 3. There are two upper and lower holes on the inside of the board. You only need to install one KO to make the shelf adjustable.





Place the movable layer board on the KO





©Movable laminate

Plug KO into non-perforated plate 3



③Door panel





The function of inserting KO KO is to prevent the drawer from falling out when it is pulled out.

Drawer part

Drawer part



Iron partition pin

KO*4



Completed picture

