


SOCE023-90CM

Please be sure to use a manual screwdriver and refrain from using an electric drill.

Product accessories and quantity

Eccentric piece installation steps

Overall partial installation



1. Product accessories and quantity (it is recommended to put more spare screws)

			
4*35 self-tapping screws	4*14 handle screw	small nails	Metal feet
B3*15 (includes 1 spare)	B14*5 (includes 1 spare)	K20*32 (includes 2 spares)	M24*4
			
Eccentric rod + eccentric wheel	Built-in door catch	Medium black (gold) color rectangular handle	
D0*7 (includes 1 spare)	L18*3	J47(gold)/J49(black)*2	
			
Iron partition pin	3.5*12 self-tapping screws	door hinge	Iron feet
K0*29 (includes 2 spares)	A1*31 (Contains 2 spare pieces)	K2*3	M44*1
			
breathable holes	Single hole door iron absorber	screwdriver	
K11*3	L19*3	1	

Kind tips:

1. When installing, please refer to the drawings to distinguish the boards.

The color of the product is not subject to the instructions;

2. Tighten the screws 70%, and then tighten them after everything is completed!

3. Some boards have a red side, and the red side faces down or inward.

4. Please read all the drawings before proceeding with installation.

5. If there are extra screw accessories, they are spare screws provided by the manufacturer!

2. Installation steps of eccentric parts



1

Screw the eccentric rod to the board



2

Find the corresponding board and insert it



3

find round hole



4

Insert the eccentric wheel into the round hole



5

Rotate 180° clockwise to lock
the board left and right



6

3. Start the installation: overall and partial installation

<1>




⑤ Bottom plate






① Left side panel




③ Right side panel




Circle the non-penetrating holes on No. 1 and No. 3 boards and face them at the bottom.


 OR 		
Iron feet	Metal feet	3.5*12 self-tapping screws
M44*1	M24*4	A1*20



Use A1 to fix M24 everywhere on the pinhole marks on both sides of the No. 5 board.




⑭ Pull plate



② Middle riser board

Note: The side with more information on board No. 2 is at the bottom



Install L18 on board No. 4, with the magnetic side of L18 facing sideways.



	
Built-in door catch	Eccentric rod
L18*3	D0*6



④ Cover




Screw the DO (eccentric rod) into the non-penetrating hole on No. 4 board


Eccentric wheel
D0*6

Insert DO (eccentric wheel) and tighten clockwise lock the board



L18 on board No. 4 is up and facing forward



DO (eccentric wheel)

DO (eccentric wheel)

DO (eccentric wheel)

DO (eccentric wheel)

DO (eccentric wheel)

④



⑫ Large back panel



Dear, for the sake of beauty, it is recommended to use tape to close the gap on the back panel until it is flush (you need to bring your own tape)

Straighten the whole



Insert K0 on boards 1, 2, and 3. There are two upper and lower holes on the inside. The purpose is to make the shelf adjustable (the shelf can be placed diagonally to accommodate larger shoes)

<9>

Place plates 6 and 7 on the KO



⑥ Large movable floor



⑦

Small movable laminate



<10>

Insert KO into the hole on the door panel



⑧ Left door panel



⑨ door panel



⑪ Right door panel



8 Left door panel



9 door panels



11 Right door panel

Medium black (gold) color rectangular handle	Single hole door iron absorber	3.5*12 self-tapping screws	4*14 handle screw
J47(gold)/J49(black)*2	L19*3	A1*9	B14*4

1. Align the KO above the door panel

Insert into the small hole below plate 4

Use A1 to fix L19 at the eye mark on the door panel.



door hinge
K2*3

