


SOCE023-140CM

Please be sure to use a manual screwdriver and refrain from using an electric drill.



1. Product accessories and quantity (it is recommended to put more spare screws)

4*35 self-tapping screws	4*14 handle screw	small nails	Metal feet
B3*15 (includes 1 spare)	B14*5 (includes 1 spare)	K20*34 (includes 2 spares)	M24*4
Eccentric rod + eccentric wheel	Built-in door catch	Medium black (gold) color rectangular handle	Single hole door iron absorber
D0*11 (includes 1 spare)	L18*4	J47(gold)/J49(black) *2	L19*4
Iron partition pin	3.5*12 self-tapping screws	door hinge	Iron feet
K0*30 (includes 2 spares)	A1*34 (includes 2 spares)	K2*4	M44*1
breathable holes		screwdriver	
K11*3		1	

Kind tips:

1. When installing, please refer to the drawings to distinguish the boards.

The color of the product is not subject to the instructions;

2. Tighten the screws 70%, and then tighten them after everything is completed!

3. Some boards have a red side, and the red side faces down or inward.

4. Please read all the drawings before proceeding with installation.

5. If there are extra screw accessories, they are spare screws provided by the manufacturer!

2. Installation steps of eccentric parts



Screw the eccentric rod to the board




Find the corresponding board and insert it



find round hole



Insert the eccentric wheel into the round hole




Rotate 180° clockwise to lock
the board left and right



Product accessories and quantity

Eccentric piece installation steps



Overall partial installation




3. Start the installation: overall and partial installation

<1>

Install L18 on board No. 4, with the magnetic side of L18 facing sideways.

	
Built-in door catch	Eccentric rod
L18*4	D0*6



④ Cover

Screw the D0 (eccentric rod) into the non-penetrating hole on No. 4 board

<2>



④ Cover



① Left side panel



③ Right side panel




Insert DO (eccentric wheel)

Tighten clockwise to

lock the board



L18 on board No. 4 is up and facing forward



Circle the small holes on No. 1 and No. 3 boards at the bottom.

<2>





② Middle riser board



⑭ pull board



Note: The side with more holes on plate No. 2 is at the bottom




<3>




⑤ Bottom plate

Circle the small hole on No. 5 plate 1



 OR 		
Iron feet	Metal feet	3.5x12 self-tapping screws
M4x1	M24x4	A1x20



Use A1 to fix M24 everywhere on the pinhole marks on both sides of the No. 5 board.

<5> Whole flip




breathable holes	small nails
K11*2	K20*12





⑫ Large back plate (two pieces in total)

Knock in the K20 with a tool hammer




<6>

	
breathable holes	small nails
K11*1	K20*8



② Large back panel




<T>



Insert K11 into the round hole



⑬ Small back panel



for the sake of beauty, it is recommended to use tape to close

the gap on the back panel until it is flush (you need to bring your own tape)


<8>

Straighten the whole



Iron partition pin

KO*24



Plug the KO into plates No. 1, 2, and 3. There are two holes on the inside, the upper and lower holes. The purpose is to make the shelves adjustable.

(The shelves can be placed diagonally to accommodate larger size shoes)

<9>


Place plate 6 on the KO



⑥ Movable laminate



<10>



Insert KO into the hole in the door panel



8 Left door panel



9 door panel



10 Door panel



11 Right door panel

<11>



⑧ Left door panel



⑨ door panel



⑩ Door panel





⑪ Right door panel

			
Medium black (gold) color rectangular handle	Single hole door iron absorber	3.5*12 self-tapping screws	4*14 handle screw
J47(gold)/J49(black)*2	L19*4	A1*12	B14*4

1. Align the KO above the door panel

Insert into the small hole below plate 4

Use A1 to fix L19 at the eye mark on the door panel.



<12>

Complete the picture

