












SOCE010-60CM

Please be sure to use a manual screwdriver and refrain from using an electric drill.



- 1. Product accessories and quantity (it is recommended to put more spare screws)

			
4*40 self-tapping screws	small nails	Eccentric wheel + eccentric rod	3.5*12 self-tapping screws
B4*28 (Contains 2 spares)	K20*34 (Contains 2 spares)	D0*5 (includes 1 spare)	A1*15 (includes 1 spare)
			
6*25 flat head screws	White rebounder (single head)	Iron partition pin	breathable hole
E4*5 (includes 1 spare)	S33*2	K0*18 (Contains 2 spares)	K11*3
			
Single hole door iron absorber	door hinge		
L19*2	K2*2		
			
screwdriver			
1			

Kind tips:

1. When installing, please refer to the drawings to distinguish the boards.

The color of the product is not subject to the instructions;

2. Tighten the screws 70%, and then tighten them after everything is completed!

3. Some boards have a red side, and the red side faces down or inward.

4. Please read all the drawings before proceeding with installation.

5. If there are extra screw accessories, they are spare screws provided by the manufacturer!

2. Installation steps of eccentric parts



Screw the eccentric rod to the board



Find the corresponding board and insert it



find round hole



Insert the eccentric wheel into the round hole



Rotate 180° clockwise to lock
the board left and right




<2>



23 Drawer bottom

- 1. Insert board No. 23
- 2. Rotate DO (eccentric wheel) clockwise



<3>



22 Drawer back panel

4*40 self-tapping screws
B4*4






The drawer part is installed

4. Overall partial installation

<1>

Place the S33 at the pinholes of No. 7 and No.


10 boards and fix it with A1 with the magnetic side facing outward.




White rebounder (single head)	3.5*14 self-tapping screws	Eccentric rod
S33*2	A1*8	D0*2



①-Left side panel



left



right


② Middle riser board

4*40 self-tapping screws
B4*2
Eccentric wheel
D0*2



⑦ roof

The arc circled on board No. 1 is up and facing backward.



Board No. 7 S33 is on top and facing forward

Circle the non-penetrating hole on plate No. 2 and face it down and to the right.

<2>




⑧ Drawer lower board



4*40 self-tapping screws

B4*4



<3>




⑨ baffle



4*40 self-tapping screws

B4*2




<4>




⑩ Door upper panel


4*40 self-tapping screws
B4*4

S33 on board No. 10 is on the upper right and facing forward




<5>



④ right panel


4*40 self-tapping screws
B4*2

Circle the arc on plate No. 4 and point it toward the back.




<6>



12 Base plate


4*40 self-tapping screws
B4*4




<7> Overall flip



6 pull plate


4*40 self-tapping screws
B4*4






26 Wooden legs



6*25 flat head screws

E4*4

The No. 26 wooden leg is fixed with 4 in front of the No. 12 board.




(Insert K11 into the round hole)



24 Back panel

breathable hole	small nails
K11*1	K20*13





Knock in the K20 with a tool hammer
(You need to bring your own tool hammer)

<10>



25 Middle back panel



	
breathable hole	small nails
K11*1	K20*6



<11>



24 Back panel

	
breathable hole	small nails
K11*1	K20*13



Dear, for the sake of beauty, it is recommended to put the back panel on the
 Use tape to close the gaps until they are flush (you need to bring your own tape)

<12> Overall alignment



Plug 0 into the non-penetrating hole of No. 2 board

KO is inserted on boards 1 and 4,

and there are two chaos on the inside.

The purpose is to make the shelves adjustable.

(The shelves can be placed diagonally to accommodate larger size shoes)

<13>



14 Large laminate



13 Small laminate



Place boards 13 and 14 on K0

The small holes on the upper side of the door panel are filled with KO




Iron partition pin
KO*2



Ⓜ Right door panel



Ⓜ Left door panel

		
Single hole door iron absorber	3.5*12 self-tapping	door hinge
L19*2	A1*4	K2*4

Use A1 to fix L19 at the eye mark on the door panel.

1 , align the KO above the door panel
Insert the small hole under the No. 7 and No. 10 plates



2. Insert K2 into the small hole on the number board first,
then align the guide hole on the door panel with the hole of
K2 and tighten it with A1 first. After the door panel is adjusted,
tighten everything

<15>

Insert KO. The function of KO is to prevent the drawer from falling

out when it is pulled out.




Iron partition pin
K0*2

<16>Complete picture

